

INSTALLATION & CLEANING INSTRUCTIONS  
HONDA AERO  
MODEL# 324 & S324

PARTS INVENTORY

<u>Item Description</u>	<u>Quantity</u>
8 x 65MM SOCKET HEAD BOLT	4
8 MM MOUNTING SPOOL	4
22 x 10.4 x 10 MM BLACK PLASTIC SPACER	4
SILICONE	1

**SADDLEBAG INSTALLATION**

1. Refer to Figure 1.
2. Assemble 8 x 65mm socket head bolt and 8mm mounting spool with chamfer on spool under head of Allen bolt.
3. Place 22 x 10.4 x 10mm black plastic spacer onto bolt.
4. Remove one rear fender mounting bolt on right side and discard.

**Information:** Do not over tighten bolts

5. Install assembly into vacant mounting location on rear fender. Tighten bolt.
6. Repeat procedure for remaining three bolts.

**Information:** Bags will be easier to mount and remove if a small amount of silicone lubrication is applied to rubber mounting points.

7. Mount saddlebags over spools on fender brace and secure with clips retained inside bags.
8. Inspect each clip to verify each clip is properly seated in retaining groove. See View "A".

## **SADDLEBAG CARE INSTRUCTIONS**

- Do not exceed 20 lbs. per saddlebag this includes sitting or standing on bags, it is a common occurrence for a non-rider to attempt to sit on bags, this also may void warranty.
- Periodically, apply a small amount of silicone lubrication to rubber mounting points. Saddlebags will be easier to mount and remove.
- Remove grease, oil or mud with mild detergent and water. For fast touch-up, *Windex or Turtle Wax Formula 2001* will restore original luster. The use of any other chemicals may discolor the saddlebags.
- Whenever possible, release locks on saddlebag lids to allow the gaskets to expand during storage.
- If you use bags to ice down drinks, later remove bags, drain water and blot up excess water. The foam interior lining is closed-cell foam and does not retain water. Leave lids open until interiors are dry.
- Use gray *Scotch Brite* scour pad (ultra-fine, only) to remove scratches & shiny spots and restore luster. This can be purchased at an automotive supply store.
- When locking or unlocking saddlebags, place one hand on top of bag near lock and apply a moderate amount of pressure while turning the key. This compresses the weather-seal enabling the locking mechanism to turn freely.
- Always inspect to verify each of the saddlebag mounting clips on inside of bag is properly installed when mounting bags. Clips fit into groove on mounting spool. Failure to perform this correctly can cause severe damage and may void warranty.

# INSTALLATION INSTRUCTIONS

## HONDA AERO

### MODEL's 324 & S324

Figure 1

← FRONT

